

| Page 1 of | 4          |
|-----------|------------|
| Version:  | 1028       |
| Date:     | 2010-12-20 |

## Outdoor Receiver Kit

QN-Kit02



#### Company Information:

| Company Name:    | Quanzhou Qinuo Electronics Co., Ltd                   |  |
|------------------|---|--|
| Company Address: | 5 Floor, Jingda Mansion, DongBin Development Area,    |  |
|                  | Fengze District, Quanzhou City, Fujian Province, P.R. |  |
|                  | China   |  |
| Postal Code:     | 362000  |  |
| Tel:             | +86-595-22569016                                      |  |
| Fax:             | +86-595-22901208                                      |  |

#### Document Information:

| Version | Update content  | Operator | Date         |
|---------|-----------------|----------|--------------|
| 1012    | Initial version |          | Apr.15, 2011 |
|         |                 |          |              |



| Page 2 of 4 |            |
|-------------|------------|
| Version:    | 1028       |
| Date:       | 2010-12-20 |


## **Description:**

- 1. 2 Channels independent set-up
- 2. Frequency 433.92Mhz
- 3. Power supply: 9V-24V DC/AC
- 4. Can learn up to 100 transmitter
- 5. Relay Spec.: 12A 14 VDC or 7A 120 VAC
- 6. Fix code technology



| Page 3 of 4 |            |
|-------------|------------|
| Version:    | 1028       |
| Date:       | 2010-12-20 |

### **Programmer Manual:**



#### Press the P1:

- -1 time to program R1 in monostable mode
- -2 times to program R2 in monostable mode
- -3 times to program R1 in bistable mode
- -4 times to program R2 in bistable mode

Hold down the key of the radio remote control that you would like to acquire until the led blinks.



| Page 4 of 4 |            |
|-------------|------------|
| Version:    | 1028       |
| Date:       | 2010-12-20 |

### Deleting:

There are two ways of deleting

#### 1.Deleting a single code:

Press P2 for about two seconds(release the key); the LED will light up, press the key on the radio remote control that you want to delete.

### 2.Deleting all codes acquired:

Press P2 until the LED turns on (about 8 seconds)