

The correct of the DL160:

1. Insert batteries;
2. Put the tool measuring surface onto the object, press ON/OFF button to power on;
3. Rotate the L-shape arm to the desired angle, the screen would display the current angle values;
4. Short press HOLD button to hold the measured values;
5. Press METER button to read the METER CUT degrees on the measured angle(only in HOLD status is available);
6. Press the Backlight icon button for 2~3s to on/off the backlight;
7. The measurement is completed, power off, remove the batteries, and keep the tool well.