

Operation Manual:

1. Open the battery cover, install a 9V battery
2. Remove the protection cap from the tester
3. Press the button to turn it on, make firm contact against the surface of the wood
4. LEDs on the tester light up and show the moisture range of the wood
5. Press the button again to turn it off, replace the cap

Warnings:

Change the battery in time when the Low-Battery

LED glows.

Replace the Pin Protection Cap after use.