

Operation Manual:

1. Install the battery;
2. Press "READ" to boost, Press "FT/M" to toggle the desired unit modes (feet ,meters)
3. .Align the product to the surface to be vertical, press READ for measuring, if you need to plus the measured lengths, press “+/=” to storage the first measured data, press “Read” again for second measurement, press “+/=” again the sum is shown on the bottom.
- 4.Press square or cubic graph buttons, measure the required length according to the displayed icon, the product will automatically display the square or cubic values after all the required lengths are measured;
5. If you need to plus the results of step 4, press "MEN INPUT" to storage the measured square or cubic values, then press square or cubic graph button, press “+/=” after a new set of values to be measured, press "MEN INPUT" again, then press “+/=” again to obtain the sum of two set data;
6. Press the left button continuously, the screen will appear "STUD" character,at the same time there will be a beep tips, moving product smoothly, the screen will appear gradually increased to the center line when closing to the edge of the beam column; move on, the vertical line will be full grid with high frequency intermittent beep;
7. The measurement is completed, power off, remove the batteries, and keep the tool well.