


PRODUCT MANUAL

BLUETOOTH CONTROLLER


For iOS / Android

HY-9027

1 Contains



2 The key distribution



3 The describe

iOS

iOS phone connection and use:

1. Turn on the phone's bluetooth, put the controller's switch to "I", press the "HOME" button, automatic matching connection.
2. After successful pairing, open the APP, click the edit button to enter the edit inter face.
3. Press "Home"+ "R1" 3-5 seconds, can turn the controller off

Android

Android phone connection and use:

1. Turn on the phone's bluetooth, put the controller's switch to "A", press the "HOME" button, automatic matching connection.
2. After successful pairing, open the APP, click the edit button to enter the edit inter face.
3. Press "Home"+ "R1" 3-5 seconds, can turn the controller off

Notice:

1. If the controller has been paired with another phone before, please unpair it on another phone first.
2. Press "HOME" button to open the controller, which will automatically connect back to the phone that was paired before.
3. The button can be set, deleted or add on the page of the APP. Please save the button after setting, deleting or adding.
4. There are popular games in the APP, and all kinds of help. If you don't download the APP, the controller can use for your phone too, but can not set anything.

If you want know more,please kindly to download this APP.



4 "Turbo" function

How to set and cancel "Turbo" function :

1. Press "Turbo" and any other function button such as A at the same time, the "A" button setting the "Turbo" function
2. Press the button which one setted "Turbo" function, and "Turbo" button at the same time can cancel
3. A,B,X,Y,R1,R2,L1,L2 can set "Turbo" function

5 Warning

- Do not expose the controller to high temperature, high humidity o direct sunshine.
- Do not allow liquid or small particles to enter the controller.
- Do not put any heavy object on the controller.
- Do not disassemble the controller.
- Do not twist or pull the cable too strongly.
- Do not throw, drop, or apply strong shock to the controller.

✱ Due to some limitations, it may not be compatible with all mobile phones, and it has been found that the incompatible mobile phones are mediatek chips.