


Shenzhen Bitvisus Technology Limited

BIT-SJT-PRO & BIT-SJT-RE


BIT-SJT-PRO:

ADVANCED VERSION



BIT-SJT-RE:

NORMAL VERSION




basic operation

1. Double-click the icon to start the software




Shenzhen Bitvisus Technology Limited

-
- 2. Click the right mouse button to bring up the menu
- 3. Picture video web software window publish




- 4. Picture in picture roaming (can be dragged freely): Right mouse button in a window to draw a box, click "open window", you can open a picture-in-picture.



Shenzhen Bitvisus Technology Limited

5. Picture video web software window publish: Put the mouse on a window, double click to make the window full screen, double click again to restore


BROWSE THE WEBSITE



Shenzhen Bitvisus Technology Limited

6. Multiple or signal source display: Video wall segmentation & single panel segmentation

Can be used with a variety of video wall controller in the store



Shenzhen Bitvisus Technology Limited

7. display plan setting: After the large-screen window opening and content display is completed, it can be saved as a plan for subsequent direct use.

DISPLAY PLAN SETTING



8. Set different time period displays solution

SET DIFFERENT TIME PERIOD DISPLAYS SOLUTION



Shenzhen Bitvisus Technology Limited

9. Subtitles: subtitles can be opened at the top of the screen, subtitles can be fixed and scrolling

Add scrolling function to subtitles



10. Only supports WIN10 system

