

Haoliyuan (Shenzhen) Electronic Co., Ltd

E-mail:julie@haoliyuan.net

Mobile:+86-15220117341

Skype ID:julie_4139

●Product Introduction



Button

Press and hold the button for 5 seconds until the LED blinks, the device will enter pairing mode

LED/PIR sensor

Blinking: The device enters pairing mode

ON/OFF: Power indicates for the device

●Quick Setup

Note: It needs to install “Smart Life” and register an account first (Search “[Smart Life](#)” in APP Store/Google Play or Scan below QR code to install APP).



Haoliyuan (Shenzhen) Electronic Co., Ltd

E-mail:julie@haoliyuan.net

Mobile:+86-15220117341

Skype ID:julie_4139

1. Power on the device

Plug USB cable into the power jack

2. Device pairing


Make sure the gateway has been added first, then press the button for 5 seconds to see the LED blinks, enter gateway homepage and click "[Search new device](#)" or "[Add Devices](#)" and follow the in-app instructions to connect the device to your gateway.

3. Device Installation

Keep the front of this device to the direction where you want to monitoring, then make sure it be installed fixed, avoid using it in places where there are air flow generated by fans, air conditioners...

●Instruction for app settings

In the device homepage, it will show the human presence status and current brightness, at the upper right corner of home page, there is a switch to enable/disable detection



Haoliyuan (Shenzhen) Electronic Co., Ltd

E-mail:julie@haoliyuan.net

Mobile:+86-15220117341


Skype ID:julie_4139

Click “**Setting**” to enter the setting page, there are some options for the device:


1. Work Mode:

There are three kinds of modes in the device, refer as below:

①.Detect Motion: Detect human motion



②.Monitor Presence: Monitor human presence




Haoliyuan (Shenzhen) Electronic Co., Ltd

E-mail:julie@haoliyuan.net

Mobile:+86-15220117341


Skype ID:julie_4139

③.Motion+Presence Detection: Monitor human presence after motion is detected



2. Setting Description

①.detection distance



It can be adjusted in three levels with 3/4.5/6 meters

Haoliyuan (Shenzhen) Electronic Co., Ltd

E-mail:julie@haoliyuan.net

Mobile:+86-15220117341


Skype ID:julie_4139

②.Sensitivity adjustment




Tips: If the detected object is in a range of 3 meters, even a low sensitivity had been set, the micromovement also can be detected.

③.Hold time



If it doesn't detect anyone, it can be set a time that how long will show nobody.

④. Enable/Disable the power indicator



⑤.Enable/Disable the notification pushing Presence Alarm

