

## Applicable Models

|                    |                                                                                                                                   |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| <b>For Huawei</b>  | P20、P20 Pro、Mate10、Mate10 Pro、Mate9、Mate9Pro、P10、For P10 plus/Huawei Mate RS Porsche、Mate10 Porsche、GloryV10、Glory10、Glory Note10 |
| <b>For Xiaomi</b>  | For Xiaomi 8、MIX series、For Xiaomi 6/6X、Redmi Pro、Note3、5C/5x/5/5s/4C/4S                                                          |
| <b>For LeTV</b>    | For LeTV full range of mobile phones                                                                                              |
| <b>For Samsung</b> | S9 series、Galaxy Note7、S8、C9/Pro、C7Pro、Note7/8                                                                                    |
| <b>For Meizu</b>   | MX6/Pro5、Pro6/6S/6Puls、Pro7/7Puls、no bule X                                                                                       |
| <b>For Nubia</b>   | Z18mini、Z17mini、Z11series                                                                                                         |
| <b>For Mito</b>    | M6                                                                                                                                |
| <b>For tablet</b>  | For Xiaomi tablet 2、For Xiaomi tablet 3、Nokia N1                                                                                  |

