


# PRODUCT MANUAL

## MULTI CONTROLLER


For PS4 / PS3 / Switch / PC / PC360 / Android

HY-9018

### 1 Contains



### 2 The key distribution




### 3 The connection

#### PS4

How to connect the PS4 console:


1. Connect the PS4 console to the power.
2. Plug the controller's USB cable into the console.
3. Wait about 3 seconds until the white LED flashes, then press the "HOME" button.
4. Wait about 2-4 seconds, the controller connects successfully when the LED changes color.



#### Switch

How to connect the switch console:

1. Connect the N switch console to the power.
2. Plug the controller's USB cable into the console.
3. Wait about 5-8 seconds, press any button, and the LED will light, then press "A" button to finish connecting.



#### PS3

Directly connect by USB cable, about 5-8 seconds.

#### PC/PC360

Directly connect by USB cable, about 5-8 seconds.

#### Android

Connect through OTG cable, about 5-8 seconds (please notice, we don't provide OTG cable)

### 4 "Turbo" function

How to set and cancel "Turbo" function :

1. Press "Turbo" and any other function button such as A at the same time, the "A" button setting the "Turbo" function
2. Press the button which one setted "Turbo" function, and "Turbo" button at the same time can cancel
3. A,B,X,Y,R1,R2,L1,L2 can set "Turbo" function

### 5 Warning

- Do not expose the controller to high temperature, high humidity or direct sunshine.
- Do not allow liquid or small particles to enter the controller.
- Do not put any heavy object on the controller.
- Do not disassemble the controller.
- Do not twist or pull the cable too strongly.
- Do not throw, drop, or apply strong shock to the controller.