

Various combinations of 3 Neon indicators identify the 3 Neon indicators identify the 6 most common wiring errors.

Confirms correct wiring

Identifies Missing earth fault

Identifies Live and neutral reverse fault

Identifies Missing neutral fault

Identifies Live & Earth reverse fault

Other faults show as