




SF120□1M SF120□1L
Vertical Type with Foot Switch



Mounting hole detail
Viewed from Direction A




Schematic	M	Push:1-2 ON Free:2-3 ON
	L	Push:1-2 ON Free:2-3 ON


Notes

3 foot switches without rear

SF120□2M SF120□2L
Vertical Type with Foot Switch



Mounting hole detail
Viewed from Direction A



Schematic	M	Push:1-2 ON Free:2-3 ON
	L	Push:1-2 ON Free:2-3 ON

Notes

3 foot switches without rear