



Download the App



AWOW Technology (shenzhen) Co.,Ltd

- Adress: 603, Jinfulai Comprehensive Building, No. 49-1 Dabao Road, Dalang Community, Xin'an Street, Bao'an District, Shenzhen, China
- Email: smartlife@cqteq.com.cn
- Facebook: [@AWOWLIFE](#)

AWOW®

USER GUIDE

Electric Heating

TH213-ES010-AWOW



WiFi Thermostat

Manual Languages: English / Deutsch / Italiano



In the box you will find

 Thermostat 1pc
 Screws 2pcs

 User Guide 1pc
 Floor sensor 1pc(optional)

Technical Data

Power Supply: 100-240VAC, 50/60HZ

Current Load: 16A

Power Consumption: < 1.5W

Sensor: NTC 10k B_{25/50}: 3950K

Accuracy: ±1°C



Set Temp Range: 5~35°C

Size: 86*86*13mm

Shell Material:

PC+ABS(flame retardant)

Dimension





CAUTION


High Voltage. The thermostat should be installed by an authorised electrician.

You will be working with mains voltage, so please protect yourself by cutting off the power installation.

Wiring Diagram


TH213-Electric is for electric heating, 16A

- 1/4: Connect to the heat device (load)
- 2: L line
- 3: N line
- 5/6: Connect to the external sensor



Installation

The thermostat fits for Standard 60mm pattress box or UK 86mm pattress box.



- Cut off power supply
- Remove the mounting plate by screw driver, pls be careful, do not damage the external sensor.
- Connect the terminals to right wires according the wiring diagram. See I
- Fix the power unit with plate in the pattress box with screws. See II
- Fix the display panel to the plate. See III

Home Screen Quick Reference



- a Current Temperature
- b Target Temperature
- c Optimum start
- d From left to right :
Loading, Lock, Cloud Connection, WiFi Connection

Press 'M': Switch mode


Press 'M' 3s: Power on or off

Press '^': Increase the temperature

Press 'v': Decrease the temperature

Press 'v' 3s: Enter the pairing WiFi mode

'M' 'v': Press 'M' & 'v' for 3s to lock or unlock



Other Operation

a. External & Internal Temperature Check:

Long press the 'M' and '^' to switch the internal temperature or the external temperature.

b. Temperature Protection Warning:

When the temperature is higher than the protection value, '^' will flash, the heater stops working, and the temperature will drop by 2°C lower than the protection value; '^' will stop flashing and the protection mode will be canceled.

c. ERR Exception :

When the 'Er' light is on, it means the sensor mode is incorrect or the sensor is broken. The temperature value on the screen will show '--'.

Advanced Settings

When the thermostat is power on, long press the '▲' and '▼' (5s), press 'M' select the setting items, and press '▲' or '▼' to select.

- 1 Window open • 2 Optimal start
- 3 Sensor type
00: Internal 01: External 02: Internal & External. Default is 00
- 4 High temperature protection:
20~90°C, Default is 28°C, '---' Cancel the protection
- 5 Swing: 1~9 °C, Default 2 °C
- 6 Temperature calibration : -9°C~+9°C, Default is 0°C
- 7 Highest target temperature: 35~90°C, Default is 35°C
- 8 Lowest target temperature: 0~30 °C, Default is 5°C
- 9 Home mode target temperature: Default is 22°C
- 10 Away mode target temperature: Default is 15°C
- 11 AUTO mode target temperature: Default is 20°C
- 12 System restart:
Press '▲' or '▼' to switch the '---' to '===' and wait for 5s
- 13 Factory setting:
Press '▲' or '▼' to switch the '---' to '===' and wait for 5s

Connect to the Internet

The thermostat works with 2.4GHz WiFi network. Before using it, Please configure WiFi signal and settings through App with smartphone or table.

- 1 Download the 'Smart life' APP .

You can get it on Google play or
Download on the App Store .



- 2 Register account .

- 3 Connect your thermostat to WiFi .



On your thermostat

Turn on the thermostat, long press '▼' key for 3s, 'WiFi' will keep flashing quickly.

On APP

Click '⊕' on upper right corner of the main page, then select 'Small home A...' in left, then slide down your figure to choose device type 'Thermostat' in right side.

Then select the WIFI network and input 'password' of the WIFI network and click 'Next' in the App page. The the thermostat wil be connected automatically.



Programming your thermostat in App

Power on/off

— Increase or decrease the set
+ temperature .

|| Click to change modes: Home,
Away, Smart(Auto),Sleep .

⚙ Click to setting parameters and
program .



Schedule Settings

Click '⚙' icon on bottom right corner of the thermostat home page in App. Then enter "Program" to set schedule.

How to create a group?

Click '  ' icon on upper right corner of the thermostat home page, then click 'Create Group' to include thermostats you want as a group.

The one who creates this group can control all rooms of the group at the same time.



How to share your device with your family member?


Select ' Share Device ' and click 'Add Sharing' to enter the account you want to share.

You can see the sharing account you have sent and the device you have shared in this page.

You can add as many as rooms you want.

Home management

Click '  ' on right bottom corner of the thermostat home page. Then you can 'Create a home' or 'Join a home' in 'Home Management'.



How to connect your device to Amazon Echo or Google Home?

Click '👤' on right bottom corner of the thermostat home page. Then enter 'More Service' to integrate to third-party service like Alexa, Google Assistant, etc. Then follow the operation steps as prompts.

After connecting your App account to your Amazon account allows you to control this WiFi thermostat through Amazon Echo speakers. (Or Google Assistant, or Tmall Genie)

You can use voice assistant to control the thermostats.



For example, you can say:

' Alexa, turn on the floor heating thermostat'
' Alexa, set the floor heating thermostat to 25 degrees '



We want **listen**you voice anytime

You are my precious customer and I will do my best to serve you.
if you need any help, please feel free to contact us



Customer service email:

Email: smartlife@cqteq.com.cn



Facebook homepage

facebook: @AWOWLIFE



Send us buyer message

via the order interface



FAQ

- Q: Can I control my electric heating film with this thermostat?
A: You can control electric heating film, cable, etc by Electric series thermostat(100-230Vac, 16A).
- Q: Can I control water heating valve actuator with this thermostat?
Y: You can control valve actuator with Water series thermostat(100-230Vac, 3A).
- Q: Can I control boiler with this thermostat?
Y: Boiler series thermostat provides volt-free contact signal for boiler(note: it provide only volt-free signal).
- Q: What type of pattress box suits for this thermostats?
A: 60mm European standard pattress box.
- Q: Can I control all thermostats at the same time in App.
A: Yes, you can creat group to control the thermostat simultaneously.