

Product Manual

To ensure the best use experience, read the user manual
carefully

Please keep this manual for future review

Thank you for using our digital learning player

In order to familiarize you with the operation of this machine as soon as possible, we provided a user manual with detailed contents, from which you can get the introduction of the product, the use method, the system settings and the use precautions. Before you use this product, please read this manual and all the information carefully, which will help you better use this product.

Statement

1. Errors or omissions may have been made in the preparation of this brochure and shall prevail in kind.
1. We reserve the right to make changes and improvements to the products described in this brochure without prior notice, based on the principle of continuous innovation and development in response to market demand.
2. In any case, we will not be responsible for the loss caused by the damage of the data stored in the machine.

Attention

This manual is designed to ensure the correct use of this MP3 by the user and to ensure that the product performs well, please read it carefully and observe it.

- Do not seriously hit the machine.
- Do not contact the machine with benzene and diluent chemicals
- Do not put the machine near strong magnetic field and electric field.
- Do not put it into water or near high temperature.
- Do not disassemble, repair or manufacture by yourself.

- Do not use MP3 and earphones when cycling, driving cars, motorcycles and other sports to avoid danger.
- Do not listen at a high volume to avoid adverse effects on your hearing.
- The battery shall not be exposed to sunshine, fire or similar overheating


Main functions

- TFT color display 240 * 320
- Full screen touch
- Support MP3, WMA, APE, FLAC, WAV, AAC and other mainstream audio formats
- Multiple playback modes: repeat off, single track repeat, all repeat, random play
- Type-C transmission
- Bluetooth 5.3
- Support search and query functions such as idiom dictionary, Chinese dictionary, Chinese character dictionary, Chinese-English dictionary and ancient Chinese dictionary
- With functions of clock, calculator and alarm clock
- Automatic browsing of e-books and pictures

Radio function

- Support TF card, maximum 128GB
- Support for multiple languages
- WIN7 and above systems

Main Buttons



Note: For the number and definition of buttons, please refer to the physical object;

1. Power 2. A-B Repeat button 3. One click button 4. Volume +
5. Volume - 6. Headphone Hole 7. Type-C 8. TF Port 9. LCD
10. Home button 11. Loudspeaker Hole

Operating instructions

On/Off/Lock screen button

a. Press and hold the power button for 3 seconds to turn on, and then press and hold the power button for 3 seconds to turn off

When the time of not operating the product reaches the user's set shutdown time, the player will automatically shut down.

(Note: This function is invalid when the player is connected to a PC or charged)

b. Short press the power button to turn off or turn on the light when the machine is turned on

Charging

Check the remaining battery power after switching on. If the battery is very low, charge it promptly to ensure normal use!

When the system enters a low battery state, it will indicate low battery and automatically switch off.

(1) Charging through adapter: connect the adapter to the power supply before charging, then plug one end of the USB cable into the adapter, and connect the other end to the USB (type-c) interface of the player to charge. It can be fully charged in about 3 hours under normal conditions. Please use the 5VDC/1A power adapter that meets the national standard and has passed CCC certification.

(2) Charging via computer USB: plug one end of the standard USB cable into the USB port of the computer, and then plug the other end into the USB (type-c) port of the player to charge. At the same time, the player can be used as a mobile disk. It takes longer to charge the product by using the computer USB interface than by using the adapter.

- When charging with PC USB interface, the current output capacity of USB interface of different PCs is different and the charging time is slightly different. It is recommended that when charging with PC USB interface, try to charge with the power off to speed up charging.

During the charging process, the charger and player have a certain temperature rise, which is a normal phenomenon.

Connect to PC

1. When the machine is switched on and off, connect the PC and the player with the USB cable provided with the machine. The machine interface appears to select the connection type: charging and transmission, charging and playing; If you do not select it within 3 seconds, the system will automatically select charging and transmission, and then the USB connection mark will appear on the machine interface, indicating that the player has successfully connected to the computer.

2. Right-click the connection letter in the lower right corner of the computer, and the system will display "Safely delete hardware". Click to exit safely; Or double-click the connection drive letter to pop up the "Safe Eject" box to exit safely.

Music

Click music to enter the lower menu, which contains: playing, all songs, favorites and other Settings and options;

Dictionary

Click the dictionary to enter the lower menu, which contains:, English dictionary, Chinese-English dictionary, Chinese dictionary Settings and options;

Recording

Click the class recording to enter the lower menu, click the lower left button to start the recording; click the lower left button again to pause the recording and click the recording again; click the lower right button to end the recording;

Listening play

Click Listening Play to enter the lower menu, which contains:
Is playing, all songs, favorites, etc and options;

Folder

Click the folder to enter the lower menu, you can view the
TF card and the local file;

Campus radio

Click the campus broadcast to enter the subordinate menu,
which contains preset radio station, user radio station,
manual tuning, automatic tuning, FM recording;

Tool

Click on the tool to enter the lower menu, which contains: alarm clock, Computer, stopwatch, wallpaper settings and options;

Setting

Click Settings to enter the lower menu, which contains Display settings, period and time, shutdown settings, and information, format information and other options;

OTG download

Can use Huawei, appo, vivo, Samsung and other mobile phones with OTG function for song transmission. Oppo or vivo needs to manually turn on the OTG switch in the Settings, and then the phone connects to the OTG download and USB cable for transmission.

Bluetooth

The Bluetooth function supports the Bluetooth earphone. The frequency step is to check the frequency steps in the manual of the Bluetooth earphone that you bought, and conduct the frequency operation. When connecting the Bluetooth earphone, remember to turn off the mobile phone Bluetooth first, so as to avoid the Bluetooth earphone being occupied by the phone.(Note: Mobile phone Bluetooth connection is not supported)

Product Specification

product name	Multi-Media Player
Dimension	80mm*59mm*13.3mm
Language	Simplified Chinese and English
LCD screen	The TFT color screen shows 240 * 320
Battery	lithium battery
Bluetooth	Bluetooth version 5.3

Audio format	MP3、WMA、APE、FLAC、WAV、AAC
Recording format	MP3、WAV
loudspeaker	1W*8ohm
Port	Typec USB2.0
picture	BMPJPG (below 1MB)
working temperature	-5°C- -40°C degrees Celsius
net weight	About 78g