

## yoga pant size chart (7/8)

yoga pants (All black) : cm					
	Size				
Part	S	M	L	XL	2XL
high of waistband	12	12	12	12	12
前浪 不含腰 front rise	17	18	19	20	21
后浪 不含腰 back rise	22.2	23.4	24.6	25.8	27
侧边长 不含腰 ( outside length without	63	65	67	69	71
内长 (inside length )	52.5	54.5	56.5	58.5	60.5
脚口 (pant opening leg)	12	12.5	13	13.5	14
(下腰缝线7厘米处) (1/2hip)	35	36.5	38	39.5	41

## BRA SIZE

ZIPPER BRA : cm					
	Size				
BRA	S	M	L	XL	2XL
1/2 胸围 chest	35	37	39	41	43
1/2 下摆 bottom	32	34	36	38	40
前中长拉链完成长 zipper size	27	27.6	28.2	28.8	29.4
小肩宽 shoulder line	3	3	3	3	3
松带剪长	64.5	68.5	72.5	76.5	80.5

