


无线直/卷发器-Hair Straighteners

Photo		
inner packaging weight	单个重量	300g
inner packaging size	单个尺寸	Ø35*H 203 /mm
Outer packaging weight	整箱重量(贴钻)	14.5KG
Outer packaging size	整箱 尺寸	L487*W474*H123/mm
Single / package / weight	单件/包装/重量	356
Single / package / size	单件/包装/尺寸	L46*W46*H227/MM
Full container / quantity	整箱/数量	36/ SET
Battery / capacity	电池/容量	4800mAh
Built-in Battery	内置/电池	Built-in Battery
Input Voltage 5V ~ 2A	输入电压5V~2A	5V~2A
Output voltage 3.7V	输出电压3.7V	3.7V
USB charging time	充电/时间	2.5~3h
160°C / 320°F	使用时间/usage time	55~60min
180°C / 356°F	使用时间/usage time	45~50min
200°C / 392°F	使用时间/usage time	35~40min
160°C / 320°F	发热速度/heating, speed	45/S(秒)
180°C / 356°F	发热速度/heating, speed	60/S(秒)
200°C / 392°F	发热速度/heating, speed	75/S(秒)
200°C / 392°F	发热速度/heating, speed	75/S(秒)
Step1 A: Open the "Cap tube";	第一步A, 打开 "盖筒"	见右图/See right
Step2 B, Turn on the "Safety switch"	第二步B, 打开 "保险开关"	见右图/See right
Step3 C, Long press "On / Off" for 3 seconds, turn on or off;	第三步C, 长按 "开/关机" 3秒, 开或关	见右图/See right
Step4 D, Double-click "On / Off" continuously to switch the temperature range;	第四步D, 连续 双击 "开/关机" 切换温度档位	见右图/See right
Step5 L, If ran out battery, use USB charging (5V / 2A).	五步L, 没电了, 使用USB充电 (5V / 2A)	见右图/See right
产品认证:		
电池认证:	CE/FCC/UN38.3空运/海运MSDS	

下方是 操作步骤



Open up
Product Name
Sleeve (A)

Open up
Product Name
Safety switch (B)

392°F
356°F
320°F
Fahrenheit temperature (E)

200°C
180°C
160°C
Centigrade temperature (E)

1. Press and hold for 3 seconds, Power on
2. Click: switch temperature off gear (C)

Power display
green yellow red
Product Name
On / OFF (D)

USB charging port
5V / 2A (F)

Operational performance description	See the operation instructions in the product drawing: B、C、D、E、F	
	(B) Product Name: safety switch	1. Start up: the machine enters the standby state; 2. Close down: the machine enters the dormant state, which acts as an insurance
	(E) Product name: temperature gear	Left: 160 °C(320 °F)、180 °C(356 °F)、200 °C(392 °F) Fahrenheit and Celsius temperature range 200 °C (392 °F) Temperature gear 180 °C (356 °F) Temperature gear 160 °C (320 °F) Temperature gear Note: Low battery reminder, The three temperature gears are the same Flashes when the battery is low
	(D) Product name: Left picture 100%, battery indicator	Charge/discharge prompt green light, yellow light, red light; The charging light flashes, indicating: charging is in progress. The long light indicates that the battery is fully charged 1. Green light indicates sufficient battery 2. Yellow light indicates that there is still half of the battery 3. Red light indicates low battery
	(C) Product Name: On/Off	1. On/off: press and hold for three seconds to turn on/off the power 2. Click: click to switch to the next temperature range