

A-980 system

Host camera :

✚ This model features list:

Functional categories	Functional subcategories	Explanation
Intercom call	Call Management center	Dial 1 can be directly call management center, ask for help or unlock
	Calling user	Dial the room number calling for business, owner can see the video in the ladder mouth
Unlock	Password to unlock	Support input password to unlock
	IC card	Support IC to unlock
engineering setup	Addressing setting	Setting the building number and web address
	Code setting	Project password Settings, public unlock password to enable and close
	Volume setting	Background volume and calls' switch and adjustment
	System information	System hardware and software information, and factory information
	Network upgrading	Automatically or manually connect to the server remotely download upgrades
	Factory reset	Pop-up prompts to remind whether confirm factory reset

Indoor monitor :

Name	parameter
display	7inchTFT-LCD touch screen
resolution	800*480
input power	DC 12V
speaker	2W*1
button	Mental drawing buttons (5pcs)
network port	RJ45 (10M/100M self-adaption, auto reverse)
defence area	8 way to play
external storage	SD card
Way to install	wall mounting
Equipment size	220*160*19.4mm

Management Center

2.4 Function

Functional categories	Function
Call	Call, Call records check, Unlock records check
Monitor	Monitor the Host Camera and General Camera. Manually switch monitoring.
Alarm	Alarm information inquiry, Alarm display
Setting	Address setting, Ringtone setting, System information, System restore
Weather Information	Weather information display

2.5 Specifications

Items	Parameter
Screen	7 inch capacitive touch screen
Resolution	800*480
Camera	2,000,000 pixels CMOS
Speaker	2W*1
Power	AC 100~240V input, DC 12V/1.2A output
Working power consumption	4~10W
Network Interface	RJ45*2
Button	Mechanical buttons
Expansion Interface	SD card, USB2.0, 3.5mm headphone jack, CVBS
Operating Temperature	0°C—40°C

1 Glossary

Name	Explanation
Indoor Unit	The terminal equipment for households. It can call other Indoor Unit, households, Management Center, Senior Management Center. It can monitor Host Camera, General Camera.
Host Camera	The equipment installed in unit door entrance. It can call the households in the unit and Management Center.
General Camera	The equipment installed in community door entrance. It can call all the households in the community and Management Center.
Management Center	The terminal equipment for Property or Security Room. It can call Indoor Unit, Senior Management Center and other Management Center. It can monitor Host Camera and General Camera.
Senior Management Center	The Systems Management Appliances which have installed “ Intelligent Building Management Center Software ”.

