

User Manual

Product Details




Name : Thermometer
Model : JL-TM01
Material : ABS+Silicone
Input : DC 5V $\approx$ 500mA
Battery : 3.7V $\approx$ 500mAh
Max power: 0.5W

How it works

1. Press any button at backside to wake up the display screen: it will auto sleep after 1 minute while not in the water, but 30 minutes in the water;
2. During the screen is on, press and hold “**S**” button for 2 seconds, access into the temperature setting, press “**+**” button to pre-set high level of temperature for sensor, built-in 4 numbers (37/38/39/40°C or 98/100/102/104°F) for choice, press “**S**” again to finish the setting;
3. Press “**C/F**” button to choose the temperature shows in °C or °F;
4. Press and hold “**C/F**” button for 2 seconds to turn on the night light, tap the silicone character to change the colors. The following modes are available: RGB Breathing > RGB Flickering > Pause color > OFF. Press and hold the button again to turn off.

How to read the screen

1. **Red droplet display:** Water temperature 40 °C (The user can set the high temperature at 37/38/39/40 °C)
2. **Green droplet display:** Water temperature 30~39 °C
3. **Blue droplet display:** Water temperature 18~29 °C
4. **Hi/Lo display:** High temperature (over 50°C) /Low temperature (below 18°C)



Open the plastic cover
Recharge with type-C cable

WARNINGS:

- This product contains rechargeable batteries, it should be charged under adult supervision.
- The power supply used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not be used with this power supply until the damage has been repaired.
- Check the power supply for damage before charging the product.
- The power supply is not a toy. Please remove it when the product has been charged.
- Do not attempt to modify or repair the product. This could damage the product and risks causing the battery to generate heat, short circuit or ignite.
- Do not use the product if it overheats, leaks, emits an odor or you notice other irregularities.
- Throw away at first sign of damage or weakness.
- This product contains batteries that are non-replaceable.
- The product is only to be connected to equipment bearing either of the following symbol:  or 
- If the external flexible cable or cord of this luminaire is damaged, it shall be replaced by a special cord or cord exclusively available from the manufacturer or his service agent.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

DISPOSAL:

- This item is labelled with a crossed-out bin, which means that it must not be disposed of with unsorted household waste but must be collected separately.
- The item should be handed in for recycling in accordance with the local environmental regulations for waste disposal in your region.



DC 5V



500 mA



RoHS



UK
CA

