


Function Introduction

Application Instruction:

- 1.Applicable device: N-Switch console/PC(Win 7/8/10)/Android tablet and smart phone,to play games after BT connected!
- 2.The structure conforms to ergonomics and feels comfortable.
- 3.3D Joystick mouldles and Button Moudles are interchangeable according to the user's own experience and habit to change their locations.
- 4.Back key L1,L2,R1,R2 auto-defined programming.
- 5.Colorful Fire breath LED back breath light.

* Due to the official game platform software upgrades or source code changes and other not resist factors caused some of the game can not be played or connected with our Gamepad, iPega company has no responsibility.iPega reserve the right of final interpretation for this.

Introduction for key functions:



Electrical Parameters:

Working voltage:DC3.7V
Working current:<35 mA
Working time:> 15H
Sleep current:<40uA

Input voltage/current:DC5V/500mA
BT 3.0, transmission distance: ≤8M
Battery:650mAh
Standby time: 30days after fully charged

Programmable key function:

- 1.Programming function is applicable for any button of A、B、X、Y、L、ZL、R、ZR.
- 2.Set up programming button: First press"+"(START)button, then press the button on back in need,white indicator will be always on after flashes for seconds.then release the button and press any function button(A、B、X、Y、L、ZL、R、ZR)which need to copy and set up successfully, after finish will quit programming mode automatically.
- 3.Cancel Programming: First press"+"(START)button, then press the programming button to quit at the same time, then complete the set up for canceling programming.