

Ozone Ionic facial steamer

Specification:

Model	FS-817	Operation System	Ozone Ionic
Power	220W	Frequency	60Hz/ 50Hz
Voltage	AC110/ 220V	Packing carton size	80*27*16cm
Lamp magnification:	3X, 5X magnifying lens for options		

Product Name	Portable Ozone hot water facial steamer with magnifying lamp
Item No.	FS-817
Voltage	110~220VAC 50/60HZ
Power	220W
Features	Deep Cleansing, Lightening, etc
Application	Moisturizing Skin care in beauty salon, beauty center, etc
Operation system	Ozone Ionic hot steaming
Service	OEM / ODM
Warranty	1 Year
Lamp magnification:	3X, 5X magnifying lens for options
Tank water capacity	680ml

Functions:

- 1.Soften the dead cells on the surface skin for the next cleaning treatment.
 - 2.Stretch skin pore for deep cleaning.
 - 3.Permeate into the skin pore, Soften the cumulated oil dirt, blackhead, cosmetic remain and dirt, which make the next cleansing treatment more efficient.
 - 4.Help the skin pore to exclude toxin.
 - 5.Soften wrinkle temporarily.
 - 6.It can accelerate blood circumfluence, add water to cell, and improve the metabolism and self-regeneration of skin cell.
 - 7.Applying the proper Chinese herbal medicine during the steam treatment, it can improve the effect of curing acnes, black spot and whiten, nourish skin.
- With aromatherapy treatment,stimulating the partial nerve and nursing the physical function in effective way.

Features:

1. Portable and electrical, durable and reliable
2. Auto water level sensor for safe operation
3. Clean water usage, no need to put any chemicals or additives
4. Comes with an auto shut-off function for safety when the water level is too low
5. 4 Omni directional rolling wheels for easy moving
6. Steam can help pores excrete toxins, can temporarily soften wrinkles
7. 3X, 5 X Diopter /Magnification for optional

Features of the portable electric beauty salon facial steamer:

1. Deep Cleansing, Lightening, Moisturizing, Nourishing ;
2. Ozone Facial Cleaning Steamer Machine combines hot vapour ;
3. The reliable workhorse of professional salons worldwide. This unit with Ozone lamp;
4. This unit comes with adjustable arm, and Ozone settings to sterilize the steam;
5. Includes built in features automatic shut off and heat protection thermostat system.

Features of the ozone hot vapour beauty facial steamer :

1. **Durability is emphasized.**
 - A. Stainless steel heating pipe is used
 - B. Made of imported PC material, the hot water cup is not fragile.
 - C. European water level detection method is used to switch off power when on water is available.
2. **Comfortable.**
3. **A stainless steel silica-gel air-guide duct is used, which does not smell bad like a rubber air-guide duct.**
4. **Nice and novel.**
5. **Low-priced.**

Magnifying Lamp function :

The light pipe produces incandescent/LED light, which is illuminated to the skin and magnified via convex lens so that the pore tissue on the skin is clear seen. Beautician may use the magnifier to make eyebrow and remove scar and nevus. The patient can get the right care, especially in removing blackheads and acne.

Advantages of the Ozone facial cleaning steamer:

All major parts made of steel or aluminum

Durable and reliable, safe

Auto water level sensor for safe operation

Plastic water jar not easy to be broken

Clean water usage, no need to put any chemicals or additives

Red line reminder on the water cup for water limit

Comes with an auto shut-off function for safety when the water level is too low

Rolling wheels for easy movement

Steam can help pores excrete toxins, can temporarily soften wrinkles.

Nice, elegant and easy to operate.

Water level security function

Rotatable spray head

Adjustable spray density

Safety automatic shut off and heat protection thermostat system

The portable beauty steamer machine is with good safety function. When the water level is too high or too low, it will automatically stop working. After adding or reducing water, you should restart the unit for reworking. You won't worry about too much hot water spit out causing injury or too little water which damages the unit.

Procedure for installation and operation(as shown in the figure)

1. Place the device onto the support stably
2. Check if the seal for the hot water cup has been tightened up.
3. Fill water from the water-filling opening until the water level gets close to the high limit for water filling
4. Switch on power
5. Press the push-button on the operating panel to heat the device or press bactericidal button.
6. Please drain all the water out of the water cup when the device is not used for a long time.

Cautions:

1. Do not place the device upside down or tilt it when it is in operation
2. Do not operate the device if no water is available
3. Clean the water cup frequently, and the power supply plug must be unplugged before the water cup is removed.

Repairs:

This device has been tested and examined strictly before factory delivery. In case any fault occurs during its operation, please send the device to our company's distributors or designated repair shops for repairs. Non-professionals shall not disassemble the device.

An anti-water-spray mechanism is specially designed for the device.

The device will not spray but give an alarm in case there is water, which indicates the anti-water-spray mechanism is working.

Water level is too high	Switch off power supply → drain our water → re-strat
Water is too turbid	Switch off power supply → clean → change water → re-start

Important instructions!

Please use ORDINARY TAP WATER instead of distilled or purified water when you use the steamer for the first time! Otherwise the unit might give an ALARM !

This item has a “low water safety alarming system” , and if it detects there is no water or not enough water left in the cup, it will give constant alarm to warn you as well as not let the machine work at all.

When the steamer is brand new, there is no eletrolyte in the cup at all, and if you use distilled/ purified water, the water is also very clean. So there is nothing for the steamer to feel like water.

Solution to this is USING ORDINARY TAP WATER or / and ADDING SALT INTO THE WATER, which will bring electrolyte iinto the cup to make the unit detect there is water inside. The steamer will now start working.

Additional user instructions:

This is appliance is not intended for use by persons(including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

That should the cord be damaged it must be exclusively replaced by the manufacturer, or his agent, or a similarly qualified person in order to avoid a hazard.

Repairs:

- 1.One year for the whole machine (start from the purchase day)
- 2.Please notice that the problems should be not caused by man-made factor or operating incorrect.
- 3.For below situation, need to pay for the repairs:
 - a.Operating incorrect.
 - b.Due to fire,earthquakes and floods and the natural factors.
 - c.Remould the machine.

d. Caused by other reasons not related with the product. facial rejuvenation dermabrasion machine

Our service:

1. OEM service

As different target price and different requirements, develop different type

2. Fast delivery

As different order quantity, arrange the fastest delivery time as required

3. Custom logo and packing service

No matter the logo printing or packing design, we can make it as request

4. Factory visit service

Welcome to visit our factory if you have time to Guangdong

5. Quick response

All request will be replied within 12 hours

Trade Terms:

1. Payment terms : T/T , Western Union, PayPal

2. Production lead time: 7-25 days

3. Samples can be delivered in 3-5 days

4. Shipping freight are quoted under your requests

5. Shipping ways: DHL, FedEx, UPS, TNT, or EMS, by Air and Sea is optional

6. Discounts are offered based on order quantities