



# Pocket Punch™

## INSTRUCTIONS:




POLY PUNCH

Place tubing into crescent. Apply downward pressure until punch pin pierces tubing. Release. Periodically wipe punch pin with fingers to remove resin build up.




EMITTER/ BARB INSERT

Insert emitter or barb into upper barb holder. Place emitter or barb against punch hole in tubing. Apply pressure until emitter barb pierces tubing. Remove tool.



EMITTER/ BARB INSERT WITH 1/4" TUBING

Install emitter with 1/4" tubing attached into small crescent slots on bottom of tool. Place shoulder of emitter on outside edge tool with 1/4" tubing pressed into smaller crescents. While holding emitter assembly in crescents, place emitter barb against punched hole in tubing. Apply pressure until emitter barb pierces tubing. Remove tool.



EMITTER REMOVAL

Place eased edge on bottom of punch handle against emitter at 45 angle. Apply pressure until emitter edge is lifted and seated into crescents. While holding emitter assembly in crescents rotate tool backwards until emitter is removed.

## PRECAUTION:

Always wear eye protection.  
Always wear safety gloves.  
Punch pin is sharp.  
Keep away from children.



CAUTION: Eye protection should be worn when using this tool