


# Smartwatch manual




Please read the manual before use


## A. Scan the QR code below to download APP.



1. Turn on Bluetooth on your smart watch
2. Turn on mobile Bluetooth, click "Fundo Wear" to search and add Bluetooth devices; see the chart below.



3. Locate the smart watch name and pair with it. The Bluetooth icon in the status bar turns in green when pairing succeeds.
4. Click to search Bluetooth, locate the smart watch name to pair. 2. Bluetooth "connected" prompts will be shown on the menu interface when pairing succeeds.



## B. Time sync

The time and date of the smart watch will sync with that of your mobile system in real-time and update accordingly after mobile Bluetooth pairing completes under the condition that the smart watch time sync function is turned on by default (settings - clock - time sync).



## C. Remote Camera

Click remote camera to shoot and preview pictures when your smart watch is unlocked. If it is iOS that you are operating on, please turn on the camera from mobile before pressing the camera button on the smart watch. Please be noted, pictures browsing is unsupported, so that you have to save it to the default folder of your iOS mobile device.



## D. Wechat and QQ Message Sync

Turn on QQ and Wechat message alert (settings menu in your mobile phone), the QQ and Wechat messages received by your mobile phone will be synced in the alert menu of your smart watch.



## E. Voice Recognition

When Bluetooth is connected, click the icon below to wake up the voice recognition function to dial by voice (this is for mobile phones with VoIP support only, iPhone is recommended)




## F. Battery Indicator

The numbers from 0-100 indicate the battery remains and charging status; charging status can also be displayed when the device is powered off.



## G. My APP

When mobile phone and smart watch are connected via Bluetooth, click the "my app" option in Fundo Wear menu to install weather and clock APP into your smart watch (for Android only)



## H. Q & A

1. Message Sync function avails in Android devices only, instead of iPhone.
2. Short service life  
It might be because of the undercharged battery, the current difference between chargers as well as the pseudo-power status display. Please make sure that it is charged for long enough (fully charged in 2 hours).
3. Bluetooth connection  
Bluetooth disconnects when your device is out of the effective range or the signal is too weak; reconnects automatically when your device is within effective range. In response to weak signals, it may disconnect and re-connect repeatedly, or an alarm suggesting APP alert function to be turned off will be sent.
4. Voice is unclear  
The distance between the mobile phone and smart watch is too far or the surroundings interfere with the signals. In this case, you are supposed to shift to another place or shorten the distance between both devices.
5. Language sync  
Language sync effectuates only in mobile phones of Android 4.4.3 or above systems after turning on the function on your smart watch. iOS incompatible.
6. Device search  
In iOS, you will have to keep the mobile APP on, rather than standby or off.