

# Brake Fluid Tester MT300

Many thanks for selecting this brake fluid tester.

The tester can be used as a digital brake fluid tester suitable for determining brake fluid quality.

Developed for professional use in automotive repair shops and in servicing.

Quality is tested and indicated on five LEDs in terms of “per cent of water in the brake fluid”.

## Ready for Brake Fluid Test

Unscrew the brake fluid reservoir, and pull off the cap of the Brake fluid tester. Dip the test probes into the brake fluid up to the plastic rim of the device.

## To Check Fluid Quality

Press the button for power on, green LED will light up. Insert the tester into reservoir for one second then the test result will be correctly indicated by LEDs. Repress the button for power off. The tester will automatically power off after about 15 seconds of inactivity.

## Product Labelling Indication

- Green: Battery OK, i.e.: No water contained in the brake fluid.
- Yellow: Less than 1% of water content in brake fluid.
- Yellow/yellow: Approx. 2% of water content in brake fluid.
- Yellow/yellow/red: Approx. 3% of water content in brake fluid. The brake fluid should be changed.
- Yellow/yellow/red/red: At least 4% of water content in brake fluid. The brake fluid must be changed urgently! Extreme danger!
- Battery (incl): One 1.5V , type AAA

## Attention

- Replace battery if the green LED not light up any longer after you press power on button . Wash the test probe with tap water after every use.
- In case of skin contact with brake fluid, thoroughly wash the affected skin or clothing with water.
- Do not expose brake fluid to the atmosphere for a long time as the fluid is highly hygroscopic!

